



8" Sleeper depth takes into account 7" from the exterior framing towards the interior and 1" extending past the exterior framing. The 1" extension is needed to support the outer track. 8" sleeper width does not take into account: pans, membranes & sealant provided by others.

Project:	File name: 2750 3 Panel Multi Slide - 1 inch Nail-fin - 1.5 inch Sleeper Sill	Date: 20200716
Notes:	Layout: 3 Panel with 1.5 inch Sleeper Sill	Drawn By: J Johnson